

TASSELLO PER CARTONGESSO VP

VP PLASTERBOARD ANCHOR

Il tassello VP in poliammide è ideale per fissaggi leggeri su cartongesso. Grazie alle ridotte dimensioni non ha bisogno di grandi spazi vuoti sul retro della parete di cartongesso. Il tassello VP non è adatto per fissaggi su pannelli di fibrocemento e su pannelli di cartongesso con rivestimenti sintetici. Per applicazioni su pannelli di spessore superiore a 15 mm è necessario fare un pre-foro.

VP

VP polyamide anchors are ideal for light fixings on plasterboard. Thanks to their small size, there is no need for a large air space behind the plasterboard wall. It is not suitable for fixings on fibre-cement panels and on plasterboard with synthetic coatings. For applications on panels over 15 mm thick, you need to drill a pilot hole.

Materiale tassello: poliammide ad alta resistenza

Materiale vite: acciaio zincato

Tipo di installazione: non passante

Plug material: high resistance polyamide

Screws material: galvanized steel

Type of installation: non-through

SEQUENZA DI FISSAGGIO • FIXING STEPS

